



Loosely assemble all nuts and bolts first to allow all holes to align