




XTS902 Water Recirculation Unit - Flow Switch ASSY

  Before you set up and use your XTS902 Water Recirculation Unit, read and follow the safety instruction in your "Instructions of use" manual

PART No.: XTSFSK		
ITEM	DESCRIPTION	QTY
1	FLOW SWITCH, 1 LT/MIN	1
2	M3 x 12 LONG PAN HEAD SCREW & WASHER	1
3	SHROUDED RECEPTACLE CRIMP TERMINAL, 6.3MM	2
4	PANEL MOUNTED IEC SOCKET (C13)	1
5	M3 x 12 LONG CSK HEAD SCREW, NUT & WASHER	2
6	IEC WIREABLE STRAIGHT CABLE PLUG (C14)	1
7	2 CORE SWITCH WIRE x 1M	1
8	FEMALE CRIMP BULLETS, 4MM	1
9	MALE CRIMP BULLET, 4MM	1
10	REINFORCED HOSE, CLEAR PVC, 8MM I/D x 300MM	1
11	REINFORCED HOSE, CLEAR PVC, 8MM I/D x 700MM	1
12	ADJUSTABLE HOSE CLAMPS, 11-16MM	2



FITTING INSTRUCTIONS

